Cooling tab

- Per-Layer Fan Controls
- Blip fan to full power when increasing from idle
- Adjust Printing Speed for Layers below ____ Seconds, Allow speed reductions to %
- Increase fan speed for layers below ____ Seconds, Maximum Cooling fan speed ___%
- Bridging fan speed override

Per-Layer Fan Controls

You can edit the fan speed on a per layer basis. This is very similar to how the temperature tab works*. The fan speed will only change when there's a command to have it change. Therefore, if you set it to 60% at layer 1, the entire print will run at 60%. The most common recommends for PLA/ABS are as follows:

PLA: Layer 1- Fan off Layer 2- Fan On 100%

ABS: Layer 1- Fan off

*When printing with multiple processes, the layer referenced is relative to where the process starts. For instance, if this process started at 5 mm (Advanced tab setting), then the layer 1 command would take place at the first layer after 5 mm.

Blip fan to full power when increasing from idle

With small fans, there's very little torque. Meaning the fans can sometimes not generate enough force to get moving, (once they're moving they're fine, but getting started can be tough), this setting can help blip the voltage to the fan and get it running. For instance, if you have Blip fan on and your PLA settings are:

PLA: Layer 1- Fan off Layer 2- Fan On 60%

The G-Code would be written to turn the fan on at 100% first (higher torque blip), then turn the fan to 60%.

;layer 2 Fan on 100% Delay .5 seconds Fan on 60%

Adjust Printing Speed for Layers below ____ Seconds, Allow speed reductions to %

This setting takes effect for layers that would otherwise print too quickly. For instance, if you printing a pyramid as seen below, you can see that the print speed lowers as the layers get smaller. You can see from the legend on the side, that the dark blue is the slowest speed, it's because the Cooling Speed Overrides are slowing this layer down dramatically because it would take far less than 15 seconds per layer.

blocked URL

Increase fan speed for layers below ____ Seconds, Maximum Cooling fan speed ___%

This is similar to the speed overrides above, but you would just be controlling fan speed. I personally have not used this feature, as I typically like to print with either 0 or 100 % fan speed.

Bridging fan speed override

For bridging it's important to get the material to solidify as fast as possible, setting a fan speed for bridging only can help accomplish this. For the rest of the bridging settings, see the Other tab.

ess Name:	Process1			
ct Profile:	BigBox Dual Titan		Update Profile Save as New Remo	
ito-Configu	re for Material		Auto-Configure for Print Quality Auto-Configure Extruders	
olorfabb X	т	- 0 0	Medum/Pest	
eneral Setti	ngs			
fil Percenta	nge:		20% 📃 Include Raft 🔄 Generate Supp	
Fatnader	Lawr Additions	Infil Support Te	mperature Cooling G-Code Scripts Other Advanced	
	Fin Controls	Jim Support le	specture county G-Case scripts Uther Advanced	
Per-Laye				
Layer	Fan Speed	Add Setpoin	Adjust printing speed for layers below 15,0 🐑 sec.	
3	10	Remove Setor	Allow speed reductions down to 20 🔅 %	
4	15			
5	20	Layer Number 1	En Querrides	
2	30	Fan Speed 60	5 % Increase fan speed for levers below 45.0 1 and	
	~		Increase tan speed for layers below <0,0 🐺 and	
			Maximum cooling fan speed 80 😳 %	
			Pridoing fan speed override 80 10 %	
Fan Optic				
Blot	an to full power when incre	easing from idle		